

COMBO DOMELOCK SETUP INSTRUCTIONS

1. Take the first box off the top of the pallet and flip it over so the bottom flaps are on top.
2. Grab the corners of each end of the box and pull it open wide.
3. Fold the big flaps in first, then push down to 90°. This will create the octagonal shape.
4. Fit the small flaps into the slots on the big flaps.
5. Squeeze the box slightly to make the final adjustment and square everything up nicely.
6. Flip & place on a pallet.

Watch the setup video here: <https://www.youtube.com/watch?v=WmfPjt348tU>

